

Nanomaterial Exposure Measurements -Challenges and Experiences-

Charles L. Geraci, Ph.D., CIH

Centers for Disease Control and Prevention
National Institute for Occupational Safety and Health

*Nanomaterials and Human Health &
Instrumentation, Metrology, and Analytical Methods
November 18, 2009*



The findings and conclusions in this presentation have not been formally disseminated by the National Institute for Occupational Safety and Health and should not be construed to represent any agency determination or policy



Exposure (Dose) Measurement Challenges

"Is Exposure Occurring?"

- What 'contaminant' is to be measured?
- Can the 'contaminant' be measured?
- Are there any guidelines?
- What dose measurement makes sense?
 - Any exposure/dose?
 - A specific portion of dose: total, respirable, etc?
- How is exposure interpreted?

Measuring Free Engineered Nanoscale Particulate Matter–“Nanoparticles”

- n The ‘free particle’ is the primary focus of toxicology (hazard) studies.
- n Definitions are ‘loosely’ accepted
- n Comfort level: long history with ultrafine particulate measurements
- n Human Exposure Challenge: the Engineered Nanoparticle as part of a complex exposure
- n What is actually encountered in the human exposure?

Can Nanoparticles be measured? Sure.



But, are you measuring the 'right' nanoparticle, and can it be done easily?

Where do I start?



The particle haystack



The engineered nanoparticle

To get the risk management process started,
it's OK to measure the haystack.

Multiple Metrics Are Being Considered In Toxicology Studies

- n **Mass:** Links to historical data, but lacks sensitivity and specificity in field exposure studies
- n **Size distribution:** More information , bur not specific in field studies and not easy in nanometer ranges
- n **Number concentration:** Fairly simple, but not specific to particles.
- n **Surface area:** Some relevance based on toxicology, technology is available, but non-specific

What is the common metric?

Toxicology: Mass/m^3 of air

Workplace: Particle number, size, mass, etc.

The Field Experience

- Methods are not 'nano material specific'
- Qualitative measurements are still the norm
- Quantitative measurements, when possible
- What is being used and seen?

Summary of Facilities Creating/Handling Nanomaterials

Facility Type	Nanomaterial, Size, Quantity	Process Description	Controls Present	Task	CPC (1)	OPC (2)	OPC (3)	Total Carbon ($\mu\text{g}/\text{m}^3$)	Evidence TEM Filter (Yes/No)
R&D Laboratory	Carbon Nanofibers; <100 nm in diameter; 500 mg/batch	Produce composite material.	Negative pressure room, laboratory hood and HEPA-filtered vacuum	Background	19,500	N/A	N/A	15–19	No
				Weighing, mixing	4,000	N/A	N/A	64–221	Yes
				Wet sawing	5,000	N/A	N/A	1,094	Yes
Manufacturer	Carbon Nanofibers; 70–200nm diameter; 50-100 μm length; 10-20 Kg/shift	Chemical Vapor Phase reactor. Chemically treat, dry and package.	Rooftop exhaust and shop vacuum with HEPA filter.	Background	N/A	12,600	1,000	12–15	Yes
				Processing	N/A	53,600–134,800	5,400–144,900	31–248	Yes
				Drying	N/A	84,200–109,200	11,500–98,400	1,839	Yes
				Manual Scooping	N/A	73,200–127,400	52,900–139,500	1,729	Yes

1. (P/cm³) 10-1000 nm

2. (P/L)300–500 nm

3. (P/L)500–1,000 nm


Examples of TEM Evidence



Before and after Sonication of MWCNT



Packing of CNF



PBZ – Metal oxide reactor cleaning

Not quantitative, but to verify presence and nature of the nanomaterial

What is the "Exposure Measurement Story"?

- n Exposures are occurring
- n Various metrics are being used
- n Little specific and quantitative data
- n Particle counts and mass/M3 most common uniform metrics
- n Highly agglomerated, complex nature
- n Toxicology studies: better characterization and more realistic doses needed – feedback from the field needed.